

SDO2 REMOTE CODING INSTRUCTIONS

Video available at www.cgdoors.com.au/maintenance/garage-door-care/



IMPORTANT: MAKE SURE THE GARAGE DOOR IS CLOSED FIRST!

CODE LEARNING

1. Open the white light cover on the **Opener**, which is on the ceiling of your garage.
2. Quickly press and release the **RED "LEARN" BUTTON**. The LED light will flash slowly.
3. On the remote that you're coding to, quickly press and release the button you want to code in. The LED light will extinguish.
4. Quickly press that same button again. The LED light will flash quickly.



Remote coding complete. Next time you press that button, the door will open/close. To code in more remotes, repeat steps above.

CODE DELETING

1. Open the white light cover on the **Opener**, which is on the ceiling of your garage.
2. Quickly press and release the **RED "LEARN" BUTTON**. The LED light will flash slowly. Press and hold the **BLACK "RUN" BUTTON**. The LED light will flash quickly.

All remotes will be deleted when the LED light stops flashing.