



SDO10 REMOTE

CODING INSTRUCTIONS



Code Learning

*** OPEN GARAGE DOOR HALF WAY AND STOP DOOR – LED LIGHT SHOULD BE EXTINGUISHED***

1. On the back of the opener on the ceiling, press and release the **Yellow Code Set Button** – The LED light will glow solid
2. Quickly press and release the remote button – the LED light will extinguish
3. Quickly press and release the remote button again – the LED light will flash quickly
4. On the next press of the remote the garage door will open
5. To code additional remotes, repeat steps 2-4

Code Deleting

1. Switch the opener off at the power supply
2. Press and hold down the **Yellow Code Set Button**
3. While holding down the **Code Set Button**, switch the power back on at the power supply
4. After a few seconds the LED light will flash quickly
5. All remote codes will be deleted when the LED light stops flashing