



HOW TO CODE SECTIONAL DOOR HAND TRANSMITTER: MODEL SDO2

- 1. Here is how to code the remote handset or wall station for the Avanti or Centurion SDO2.**
- 2. Always make sure you have a safe means of working at height because you will need to comfortably reach the opener.**
- 3. Open the white light cover on the motor unit.**
- 4. Briefly press the RED learn button, the GREEN LED will flash slowly.**
- 5. Now press and release the button on the transmitter you wish to use and the GREEN LED will stop flashing.**

6. Quickly press and release the button on the hand transmitter again, the GREEN LED will now quickly flash indicating the code has been accepted.
7. Press the hand transmitter a third time and the door will operate and you are all done.
8. If you have more than one hand transmitter or wall button to code, simply repeat this process.