



HOW TO DELETE SECTIONAL DOOR OPENER CODES: MODEL SDO2

- 1. Here is how to delete the remote handset or wall station to your Avanti or Centurion SDO2 opener.**
- 2. Always make sure you have a safe means of working at height as you will need to comfortably reach the opener.**
- 3. Open the white light cover on the motor unit and briefly press the RED button.**
- 4. The GREEN LED will flash slowly.**

5. Press and hold the BLACK run button, the GREEN LED will flash rapidly, and all codes are now removed. You will now need to recode any transmitters and wall button you wish to use.
6. Briefly press the RED learn button.
7. The GREEN LED will flash slowly.
8. Now press and release the button on the transmitter you wish to use, and the GREEN LED will stop flashing.
9. Quickly Press and release the button on the hand transmitter again.
10. The GREEN LED will now quickly flash, indicating the code has been accepted.
11. Press the hand transmitter a third time and the door will operate, and you're all done.
12. If you have more than one hand transmitter or wall button to code, simply repeat this process.