



FACTORY RESET FOR SECTIONAL DOOR OPENER: MODEL SD04

1. Open door all the way.
2. Turn opener off at the power.
3. As you turn the power back on, briefly hold the RED learn button in (approximately 5 seconds) then release.
4. Opener display will scroll through a few different codes. When it settles on LL please press the WHITE light on the base of the opener, which will be flashing.
5. The door will close, then open, then close all by itself. Let it do this.
6. On the last close of the door the factory re-set is complete, and the door will function as it should.